


FA007


使用說明與零件圖 INSTRUCTION AND PARTS LIST






CONTENTS 目錄 JBP4

CONTENTS 目錄	
CO-MACHINE BODY1 機體下拉布輪	
C1-UPPER SHAFT MACHANISM3 上軸結構	
C2-NEEDLE BAR MECHANISM-FEED MECHANISM5 針柱與送布傳動結構	
C3-PULLY MECHANISM····································	
C4- PRESSER BAR MECHANISM 壓腳柱結構	· a
C5-LOOPER MECHANISM ************************************	131
C6-UPPER THREADING MECHANISM 上導線張力結構	
C7-LOWER THREADING MECHANISM 下導線張力結構	
C8-LOWER SHAFT MECHANISM-GAUGE PARTS17 下軸結構與針位組	
C9-GAUGE PARTS(SP) SP 19 針位組	
C10-GAUGE PARTS (DP) DP21 針位組	
C11-PULLER DEVICE MECHANISM DP、SP23 上拉布輪結構	
C12-ACCESSORIES 25	





DEE	market and and		1.
REF. NO.音 C0-0	『件編號』 1 ■ N	NAME OF PARTS 說明 MACHINE HEAD 機體(上)	Amt req需求
C0-C	2 1	MACHINE REST BOARD 機體(下)	1
C0-0	4 (DIL PLUG 油塞	1
C0-0	5 L	OWER WHEEL 拉布輪	1_1_
C0-0 C0-0	5-1 L	OWER WHEEL 拉布輪 OWER WHEEL CONNECTION 拉布輪軸	1
C0-0	7 (DNE WAY TRIANGULAR AXLE 單向三向軸片	2
C0-0	8 (ONE WAY STILL SPRING 單向彈警	6
C0-0	9 0	DNE WAY STILL BALL 單向滾珠 DNE WAY PUSHING PLATE 單向推輪	6
C0-1 C0-1	1-1 F	NE WAT POSITING PLATE 单向推幅 PIN 銷	1 1
C0-1	2-1 F	EED DOG PUSHING PLATE LINK 推輪連桿	1 1
C0-1	2A S	SCREW 合葉螺釘	1
C0-B	17-1 F	PULLER COVER 導蓋(右)	1 1
C0-A C0-1	7.3	PULLER TOP COVER 護輪蓋 PACKING 導蓋	1
C0-1	8 F	PLASTIC COVER 橡膠塞	2
C0-X	28-1	SCREW 11/64×40 螺釘	2
C0-X	31 5	SCREW 9/64×40 L8 螺釘	3
C0-X	67 8	SCREW 3/32×56 螺釘	3
C0-X C0-X	77	SCREW 3/32×56 L6 螺釘 SCREW 11/64×40 L9 螺釘	3
X		SOLVENT LIGHTY TO EN 1987 P.	
9			4 4
F			
	70		
	9		N PE
			+
100			
1 P			100
	-		1 1 1
		J' ALJ' A	
			1
	-		_
		- V)' - V)'-	+
		A ' A '	
	-81		
. 0			14
10.5	7		
			. 0 24
The same			1 4 W
	-		AU
			-
W. P	+		
10			
1			100
	-		
		0.00	
20 10	W .		
	9	CALL	
- N			+
		\sim	
	A		



UPPER SHAFT MACHANISM


OPPER SHAP	- I MACHANISM	
REF. NO.部件編號	NAME OF PARTS 說明	Amt req需求量
C1-01	PULL BAR ENDING SCREW 合葉螺釘	1
C1-02	VERTICAL PULL BAR 傳動連桿	1
C1-03	PULL BAR BEARING 滾柱軸承	2
C1-04	VERTICAL PULL BAR FIXING SCREW 合葉螺釘	1
C1-04-1	WASER 墊圈	
C1-Y2	PULL BAR SCREW NUT 止動螺母	1
C1-06	UPPER SHAFT 上主軸	1
C1-06-1	UPPER SHAFT 上主軸 BALL BEARING 6202 軸承	
C1-07 C1-08	BEARING SUPPORT 軸承圈	
C1-08	OIL STOPPER 油封	1
C1-7-1	FIXING BUSHUNG 上軸套(前)	
C1-9-1	CHOCK RING 定位圏	i
C1-10	BEARING CASE ASSEMBLY 軸套筒	i
C1-11	BEARING 6302 軸承	- i
C1-12	OIL TANK 儲油器	
C1-13	OILGAUGE WINDOW 油鏡	1
C1-14	PACKING 油封墊圈	1
C1-15	OIL GAUGE FLANGE 儲油器蓋	1
C1-16	OIL TANK PACKING 止油銅墊圈	1
C1-17	PACKING 橡膠墊圈	1
C1-18	UPPER WHEEL ECCENTRIC WHEEL 偏心凸輪	1
C1-18-1	ECCENTRIC WHEEL WASHER 凸輪蓋	1 1 1
C1-18-2	BEARING 滾柱軸承	1_1_
C1-18-3	SCREW 9/64×40 螺釘	2
C1-19	UPPER WHEEL MOVING PULL BAR 凸輪傳動連桿	
C1-21	PULL BAR SCREW NUT 合葉螺釘	1
C1-22 C1-22A	FIXING PULL BAR SCREW WASHER 止滑墊圈 WASHER 墊圈(厚PL,PL-M,SP)(薄PL,PL-M)	2 2
C1-22A	PULL BARSCREW NUT 螺母	2
C1-23	THICKNESS ADJUSTING PULL BAR 擺動傳桿	2
C1-25	PULL BAR FIXING PULL BAR 螺釘	2
C1-26	UPPER WHEEL CONNECTION 傳動軸	1
C1-27	MOVABLE LEFT-RIGHT CHOCK RING 定位圏	
C1-29	CONNECTION COPPER TUBE 銅套筒	2
C1-30	VERTICAL PULL BAR 雙頭合葉螺釘	Time
C1-31	WASHER 墊圈	
C1-102	BEARING FIXING SCREW 外牙螺母	1
C1-102-1	BEARING FIXING BUSHING 緊壓套筒	O 1
C1-X3	SCREW 15/64×28 螺釘	1
C1-X4	SCREW 15/64×28 螺釘	1
C1-X5	SCREW 9/64×40 螺釘	4
C1-x6	CAP SCREW 覆蓋螺釘	1
C1-X7	SCREW 1/4×28 螺釘	2
C1-X9	SCREW 15/64×28 螺釘	2
C1-X38-1	SCREW 11/64×40 螺釘	2
- 7-4		-
- 14		
		- A-
-		2 4 5
		- 11
	AT CAT L	777
7		
200		
W. W.		67.4
1.0		0.7
/		1000
		DV
		13
		-
-44		
		-
7	A	- 3
-		
4		






NEEDLE BAR MECHANISM-FEED MECHANISM

REF. NO.部件編號	NAME OF PARTS 說明	Amt req需求量
C2-01	NEEDLE BAR CRANK 固定軸	1
C2-01	NEEDLE BAR CRANK 固定軸 NEEDLE BAR CRANK BOD 提升連桿	1
	NEEDLE BAR CRAIN BOU 促升連件	
C2-03	NEEDLE BAR BRACKET 針柱夾	1
C2-03-1	NEEDLE BAR BRACKET 針柱夾	1_
C2-04	WICK 油蕊	1
C2-05	OIL LEAK PROOF CAP 防油蓋	1
C2-C6	WICK 油蕊	1
C2-07	NEEDLE BAR GUIDE SLIDE BLOCK 四方滑塊	1
C2-08	NEEDLE BAR GUIDE 導軌	The same
C2-09	NEEDLE BAR 針柱	1
C2-09-1	NEEDLE BAR 針柱	1
C2-10	NEEDLE BAR BUSHING (UPPER) 針柱套筒(上)	1
C2-10-1	NEEDLE BAR BUSHING (UPPER) 針柱套筒(上)	1
C2-11	NEEDLE BAR BUSHING (LOWER)針柱套筒(下)	1
C2-11-1	NEEDLE BAR BUSHING (LOWER)針柱套筒(下)	1
	TUDEAD TAKE DOSHING (LOWEN)對性裏間(下)	
C2-12	THREAD TAKE-UP CRANK 平衡凸塊	1
C2-12-1	THREAD TAKE-UP CRANK 平衡凸塊	1
C2-14	OIL CAP 橡膠塞	1
C2-15	NEEDLE 針(PL, SP#22)(PL-M, SM#18)	3
C2-16	FEED DOG ECCENTRIC AXLE 調節凸輪	1
		-
C2-17	WASHER 墊圈	
C2-18	ECCENTRIC WHEEL SLEEVE 銅滑塊	1
C2-C19	ECCENTRIC WHEEL WITH SCREW 上下凸輪	1 4
C2-20	ECCENTRIC WHEEL SLEEVE 銅滑塊	1
C2-C21-1	FEED BAR SLIDE BLOCK ASSEMBLY 送布傳動曲柄	
C2-22	PACKING 油封墊圈	1
C2-23	FEED LIFTING FORK 叉動柄	1
C2-24	FEED BAR SLIDE BLOCK ASSEMBLY 四方滑塊	1
C2-C25	FEED BAR ECCENTRIC SHAFT 偏心軸	1
C2-26	FEED DOG ECCENTRIC SET 固定座	1
C2-X7	SCREW1/4×40 螺釘	5
C2-X8	SCREW11/64×40 L12 螺釘	4
C2-X9	SCREW 15/64×28 螺釘	5
C2-X10	SCREW 15/64×28 螺釘	2
C2-X14	FEED ECCENTRIC ADJUSTING SCREW 倒位螺釘	11
C2-X31-1	SCREW 9/64×40 螺釘	1
C2-X49	SCREW 9/64×40 L5 螺釘	1
C2-X66	THREAD TAKE-UP CRANK 平衡凸塊	
A 7 T		
2011		
	3 , 3,	
	2 , 3 , 3 , .	
		2
		A
		A
		A
		A
		2




PULLY MECH REF. NO.部件編號	NAME OF PARTS 說明	Amt req需求
C3-01 C3-02	PULLEY 皮帶輪 TIMING BELT WHEEL ASSEMBLY (SUPPER) 同步皮帶輪(上)	1
C3-03 C3-04	TIMING BELT WHEEL ASSEMBLY (LOWER) 同步皮帶輪(下) TIMING BELT 同步時規皮帶	1
C3-05 C3-06	BELT COVER 皮帶座 BELT COVER PLATE 皮帶座蓋板	1
C3-07	PACKING 防油墊片 PULLEY COVER BASE 配重固定塊	1
C3-08 C3-09	PULLEY COVER 皮帶輪護蓋	1
C3-10 C3-20	WASHER 墊圈 SPRING COIL O型彈圈 SCREW1/4×28 螺釘	3
C3-X01 C3-X07	SCREW1/4×28 螺釘 SCREW1/4×28 螺釘 SCREW1/4×28 螺釘	<u>2</u> 5
X3-X09 C3-X18	SCREW 15/64×28 螺釘	2 2
C3-X22 C3-X79	SCREW 7/16×14 螺釘 SCREW 3/16×32 L8 螺釘	2 2
C3-X19	SONEW 3/10人32 20 s宗訳	
-		
4 16		
		- 6
		100
-		
7		4 11
		-
		1
	A A Y	
		1
A RES		
		2248
	21, 21,	9011
100	1231	12
		1 74
		P.
	A 40 A	400




PRESSER BAR MECHANISM

REF. NO.部件編號			国宝、15
C4 04		Amt rec	(前水) 1
C4-01	PRESSR BAR 壓腳柱		1
C4-1A	PRESSR BAR EMA	_	1
C4-1B	PRESSR BAR 壓腳柱		1
C4-02	FACE PLATE UPPER HINGE ASSEMBLY 蝶型後鈕		1
C4-03	STEEL BALL 鋼珠		1
C4-04	PRESSER BAR BUSHING (UPPER) 壓腳柱軸套(上)		
C4-05	PRESSER BAR BUSHING (LOWER) 壓腳柱軸套(下)		1
C4-5-1	PRESSER BAR BUSHING (LOWER) 壓腳柱軸套(下)		1
C4-06	FACE PLATE (LOWER) 前蓋板(下)		1
	PACKING 防油墊片		1
C4-07	PACKING 防御蛇石		•
C4-08	PRESSER BAR CLAMP ASSEMBLY 壓腳柱夾		1
C4-09	PRESSER BAR CLAMP SPRING 壓力板	1	1
C4-10	PRESSER BAR CLAMP SPRING PIN 定位銷		1
C4-11	PRESSER BAR CLAMP SPRING ASSEMBLY 上壓力彈片	9	1
	CUIDE WACHED 点点数比		_
C4-12	GUIDE WASHER 定向墊片		1
C4-13	WING NUT 蝶型螺母		1
C4-14	PRESSER BAR LIFTER 壓腳提放勾		1
C4-15	KNEE LIFTER LEVER 壓腳提放柄		1
	WILE LIFTED CODING FROM HEADING		1
C4-16	KNEE LIFTER SPRING 壓腳提放彈簧		_
C4-17	PRESSER FOOT LIFTER CHAIN ASSEMBLY 傳動鏈條		1
C4-B18	FACE PLATE (UPPER) 前上蓋		1
C4-19	STOPPER SPRING PLATE (L) 彈片勾(外)		1
	STOPPER SPRING PLATE (S) 彈片勾(內)		1
C4-20	STOFFER SERING FLATE (3) 坤片以(内)		
C4-24	OIP CAP 油塞	_	1
C4-X8	SCREW11/64×40 螺釘		1
C4-X9	SCREW 15/64×28 螺釘	1 1	2
	PRESSER ADJUSTING SCREW 全牙螺釘		1
C4-X25		_	
C4-X26	STUD SCREW 15/64×28 螺釘		1
C4-X27	STUD SCREW 5/16×28 螺釘		1
C4-X31	SCREW 9/64×40 L10 螺釘		3
C4-X44	SCREW 9/64×40 螺釘		4
C4-A44			
C4-X60	SCREW 9/64×40 螺釘		1
C4-X95	SCREW 9/64×40 螺釘		1_
C4-Y02	SCREW 3/16×32 螺母		1
C4-D2-27	RUBBER PLUR 橡膠塞		1
C4-D2-21	NOBBER FLOR 家珍安		
		100	198
			17
		ST. ALLE	10
		2	




LOOPER MECHANISM

LOOPER ME	SHANISM		
REF. NO.部件編號	NAME OF PARTS 說明	Amt req	需求量
C5-02	ECCENTRIC WHEEL SLEEVE 銅滑塊	1	
C5-C3	LOOPER FEEDING FORK 滑動叉		
C5-C4	LOOPER FEEDING SHAFT 滑動叉(軸)	1	
C5-C5	LOPPER FEEDING SHAFT BRACKET 滑動叉基座	1	_
C5-06	PIN 叉銷	_ 1	
C5-C7	LOOPER FRONT-REAR TRANSMISSION 前後驅動連桿		
C5-C8	SLIDE BROCK SHAFT 固定軸牙	1	
	LOOPER LEVER SHAFT ?節固定軸	1	
C5-09			
C5-10	PACKING 墊圈	1	
C5-C11	CONNECTING ROD GUIDE PLATE 上下驅動連桿	1	
C5-12	WASHER 墊圈	1	
C5-C13	LOOPER SHAFT CLAMP 傳動軸夾	1	
C5-A14	LOOPER SHAFT 傳動軸	1	
C5-C15	LOOPER SHAFT BUSHING (F) 傳動軸套筒(後)	1	à
C5-16	LOOPER SHAFT BUSHING (B) 傳動軸套筒(前)	_ 1	
C5-17	SET COLLAR 定位夾	0	2
C5-C18	FORWARD ARM CONER ASSY 平面蓋板	1	
C5-C19	PACKING 防油墊片		
C5-20	OIL GAUGE 探油棒	1	
C5-20			
C5-21	PACKING 橡膠墊圈	3	
C5-22	CAP PLATE 下軌蓋	1	
C5-23	PACKING 防油墊片	1	
C5-25	"8"TYPE TRANSMISSION DEVICE 8字銅連桿	1	
C5-26	ECCENTRIC WITH SCREW 小門輸	1	
C5-27	EYEPIECE H型連桿	_ U1	-4
C5-C28	STEEL BALL 萬向滾珠		10
C5-C29	LOOPER SLIDE BASE 連桿固定片		(A) 7
C5-C30	WASHER 波浪彈片	- 1	
C5-C31	LOOPER FEEDING FORK 叉動柄		_
C5-32		1	
C5-32		1	
C5-33 C5-702	SQUARE BALL 四方滑塊	1	
C5-X9	SCREW 15/64×28 螺釘	2	
C5-X28	SCREW 11/64×40 螺釘	1	
C5-X28-1	SCREW 11/64×40 螺釘	10.1	
C5-X31	SCREW 11/64×40 螺釘	1	
C5-X32	SCREW 11/64×40 螺釘	2	
C5-X34	SCREW 3/16x32 螺釘		
C5-X35	SCREW 3/32×56 螺釘	2)
C5-X36-1	SCREW M3.5 L=10 螺釘	4	
C5-X37	SCREW 11/64×40 螺釘	1	
C5-X38-1	SCREW 11/64×40 螺釘	2	
C5-X42	SCREW 1/2x28 螺釘	3	
C5-X50	SCREW 9/64×40 L=5 螺釘	4	
C5-X56	SCREW 15/64×28 螺钉	2	
C5-X30	NUT 15/64×28 螺釘	1	
C5-101	1801 13/04/20 號到	- 11	
		-	
			1
		- 4	6 _ 2"
		_ (m) '	100
P		Pa	The same
		-0.7	A. TO
		7 10	F
-			
			_
	ATT ATT		
			7.0
100	ATAPT V ATAPT V	900	100
		10	The same
1			1
		A0	
		-	
A A T			
			
		400	
		A	
		1	
470		b :	_




UPPER THREADING MECHANISM


C6-01	NAME OF PARTS 說明 UPPER THREAD GUIDE RETAINER 上導線座	Amt req需	X
C6-03	BRACKET 過線片	1	_
C6-06	THREAD HANGER 導線圈	1	
C6-07	LINE GUIDE DEVICE 倒位基座	1	1
C6-7-1	PIN 銷	1	
C6-08	TENSION SPRING WASHER 彈簧墊圈	3	4
C6-09	TENSION SPRING WASHER 彈簧墊圈	3	_
C6-10	NUT 螺母	3	_53
C6-11	TENSION DISC 沙拉片	6	_
C6-12	TENSION DISE PRESSER 張力墊圈 UPPER THREAD TENSION SPRONG 張力彈簧	3	_
C6-13	UPPER THREAD TENSION SPRONG 張力揮責 UPPER THREAD RELEASE PIN 銷	3	_
C6-14 C6-15	THREAD RELEASE PIN	1 1	_
C6-15	ITHICAD RELEASER SHAFT	1	_
C6-16	-		_
C6-17	UPPER THREAD TENSION SUTD SCREW 過線固定片	3	-
C6-23	LOWER THREAD TENSION PLATE 張力夾線片	4	_
C6-24	PIN 銷	1	
C6-25	TENSION RELEASE CRANK 連桿	1	-
C6-26	TENSION RELEASE CONNECTING BAR 上線鬆放提柄	1	_
C6-27	THREAD RELEASER LEVER 撥線片	1	-
C6-28	THREAD RELEASER LEVER SAFT 撥線軸	1 1	_
C6-29	TENSION RELEASE CONNECTING ROD 連桿	1	-
C6-30	TENSION RELEASE LINK 小連柄	1	Ť
C6-31	TENSION RELEASE SUTD 壓腳柱夾	1	Í
C6-32	THREAD GUIDE 導線勾	1	Ť
C6-33	WASHER 墊圈	1	ř
C6-34	UPPER THREAD TAKE-UP LEEVER ASSEMLY 天秤	1	È
C6-34-1	UPPER THREAD TAKE-UP LEEVER ASSEMLY 天秤	1	-
C6-35	THREAD CHECKER 天秤夾線片	1	-
C6-36	SPRING 彈簧	1	-
C6-37	LOWER THREAD GUIDE 導線勾(D)	1 1	_
C6-38	WASHER 塾图	1 1	7
C6-39	UPPER THREAD TENSION REGULATOR ASSEMBLY ?通導線片	1	f
C6-A40	UPPER THREAD TENSION SUTD ASSEMBLY 張力調節軸	1	Ξ
C6-41	UPPER THREAD TENSION SPRING 彈簧	1	f
C6-43	WASHER 墊图	1	-
C6-44	UPPER THREAD FASTENING CAM WITH SCREW 上線張力凸輪	1	-
C6-X8	SCREW 9/64×40 螺釘	2	_
C6-X9	SCREW 15/64×28 螺釘	1	_
C6-X31-1	SCREW 9/64×40 螺釘	1 1	-
C6-X34-1	SCREW 11/64×40 螺釘	2	_
C6-X44	SCREW 9/64x40 L=5 螺釘	1 1	_
C6-X47	SCREW 11/64×40 螺釘	 i	-
C6-X47	SCREW 9/64×40 螺釘	2	_
C6-X49	SCREW 9/64x40 L=6 螺釘	Ī	_
C6-X50	SCREW 9/64×40 螺釘	1	_
C6-X51	SCREW 11/64×40 螺釘	1	_
C6-X53	SCREW 9/64×40 螺釘	1	-
C6-X54	SCREW 3/32×56 螺钉	1	-
C6-X56	SCREW 15/64×28 螺钉	2	-
C6-X58	UPPER THREAD TENSION STUD SCREW 叉口合葉螺釘	3	-
C6-X59	SCREW 11/64×40 螺钉	1 1	T
C6-X65	SCREW 3/32×56 L=4 螺釘	2	f
C6-B26	TENSION RELEASE CONNECTING BAR 上線鬆放提柄	2	f
C6-C22	THREAD TAKE-UP COVER 天秤護蓋	1	-
C6-Y04	NUT 11/64×40 螺釘	1	Τ
		1	_
			_
			_
			_
			3
E			É
		0.70	d
		10.0	Ē
		180	
_A(ii)		A7	
		N.	_
2 4 8			_
- 11 11 -			_
			_
40			_
		4	_
			_
1		00	_
	AV AV	-	_
	711 711	3	_



LOWER THREADING MECHANISM


REF. NO.部件編號	NAME OF PARTS 說明	Amt req需求
C7-01	LOERT THREAD GUIDE RETAINER 導線架(上)	1
C7-02N	THREE PIPE-LINE THREAD TUBE 三線過線管	1
C7-03	BRACKET 過線片	1
C7-03N	THREAD TUBE CLAMP 導線圈	6
C7-06	LOWER THREAD GUIDE SUPPORTER 支架輔助	1
C7-06	LOWER THREAD GUIDE HINGE ASSEMBLY 活動鈃(上)	
		2
C7-12-1	LOWER THREAD GUIDE HINGE ASSEMBLY 活動鈕插銷	2
C7-17	LOWER THREAD COVER 橡膠墊	2
C7-A10	LOWER THREAD COVER 下前蓋	1
C7-A11	PLATE SPRING 彈簧勾	2
E7-A12	FIXING PLATE 活動鈕(下)	2
C7-A14	LOWER THREAD TENSION BRACKET 三通過線片	1 1
C7-A14-1	THREAD GUIDE 穩線片	+ +
	I ONE TUDE A CONTROL OF TAINED OF TA	+ +
C7-A17	LOWER THREAD GUIDE RETAINER ?通過線片	1 1
C7-A18	PLATE SPRING 彈片勾	2
C7-A50	LOOPER SIDE COVER (R) ASSY 彎針護蓋	1
C7-A51	LOOPER SIDE COVER (L) ASSY 彎針護蓋	1
C7-A55	LOWER THREAD GUIDE 過線片	1
C7-C20-B	THREAD TENSION ROD 沙拉螺柱	3
C7-C21-B	LOWER TEREAD TENSION BRACKET 沙拉托架	3
	LOWER TEREAD TENSION NUT 沙拉螺母	3
C7-C22-B		3
C7-C23-B	LOWER TEREAD TENSION PLATE 沙拉片	6
C7-C25-B	LOWER TEREAD TENSION SPRING 沙拉彈簧	3
C7-27	THREAD TAKE-UP LEVER COVER 護線蓋	1
C7-28	SPRING 彈簧勾	1 1 2
C7-29	LOWER THREAD TAKE-UP LEVER FRAME 過線輔助架	1
C7-30	LOWER THREAD TAKE-UP LEVER COVER SHAFT 銷	1
		1
C7-31	LOWER THREAD TAKE-UP LEVER BASE 過線支架	
C7-32	GUIDE PLATE 過線輔助架	1
C7-33	WASHER 墊圈	1
C7-34	LOERT THREAD GUIDE PLATE 固定片	1
C7-35	SCREW 彈簧	1
C7-36	WASHER 墊圈	1 1
C7-37	LOWER THREAD GUIDE(LEFT) 彈片扣	1
C7-39	LOWER THREAD GUIDE(LEFTRIGHT) 導線勾	2
		2
C7-40	LOWER THREAD GUIDE(LEFT) 導線勾	1
C7-41	LOWER THREAD GUIDE PLATE 固定片	1
C7-44	LOWER THREAD TAKE-UP DISC ASSEMBLY 配線円輪	1
C7-45	LOWER THREAD FEED TUBE 過線管	1
C7-47-1	LOOPER THREAD GUIDE BRACKET 針受座	1
C7-48	THREAD CUTTER GUIDE PLATE 切線刀	1
C7-49	THREAD CUTTER 切線刀	1 1
C7-A50-2	STOPPER SPRING PLATE 彈片勾	2
C7-A50-3	PIN 銷	4
C7-A50-4	FACE PLATE UPPER HINGE ASSEMBLY(R) 蝴蝶後扭(右)	1
C7-A51-4	FACE PLATE UPPER HINGE ASSEMBLY(L) - 蝴蝶後扭(左)	1
C7-C68	PIN 銷	1
C7-X9	SCREW 15/64x28 螺釘	1
C7-X31電	SCREW 11/64×40 螺釘	3
	SCREW 11/64×40 螺釘	
C7-X31-1		12
C7-X31-2	SCREW 9/64×40 L10 螺釘	2
C7-X44	SCREW 9/64×40 L5 螺釘	7
C7-X45	SCREW 9/64 螺釘	2
C7-X50	SCREW 9/64 螺釘	2
C7-X60	SCREW 9/64×40 L4 螺釘	1
C7-X64	SCREW 3/32×56 螺釘	3
C7-X65	SCREW 3/32×56 L4 螺紅	2
	SCREW 3/32x30 L4 「緊迫 SCREW 1/4x40 「螺釘	
C7-X66		2
C7-X67-1	SCREW 3/32×56 螺釘	6
C7-X92	SCREW 9/64×40 螺釘	1
C7-X95	SCREW 9/64x40 螺釘	1
C7-Y05	NUT 9/64×40 螺母:	2
	THE TANK OF THE PARTY OF THE PA	
Til.		10 F 10
	100	0.0
		10.10
		11 1
		10
		1 3/1
67.07		
	747 747	1
		1
		1
		4
		A
		A
		A
		A






LOWER SHAFT MECHANISM-GAUGE PARTS

REF. NO.部件編號		
	NAME OF PARTS 說明	Amt req需求
C8-C1	LOVER SHAFT 下主軸	1
C8-02	BEARING 6200 Z 軸承	1
C8-03	BEARING 6201 Z 軸承	1
C8-04	BALL BEARING BUSHING 內套筒	1
C8-05	BEARING CASE ASSEMBLY 軸套筒(下)	1
C8-05	DEARING CASE ASSEMBLY 軸套同()	
C8-06	BEARING FIXING BUSHING 緊壓套筒	110
C8-07	NEEDLE CLAMP WITH SCREW 針夾	1
C8-08	NEEDLE PLATE 針板	1
C8-09	PRESSER FOOT ASSEMBLY 壓腳組	1
C8-10	FEED DOG 送布齒	1
C8-C10-11	NEEDLE GUARD 針受	1
C8-11	BEARING 6302 軸承	1
C8-14H	LAPPER ASSEMBLY 導布架喇叭	1
C8-15	SPRING 彈簧	1
	LOOPER LONG 彎針(長)	-
C8-18	LOOPER LONG 写新(技)	
C8-A19	LOOPER HOLDER (SHORT) 彎針台(短)	
C8-A20	LOOPER HOLDER (MIDDLE) 彎針台(中)	
C8-A21	LOOPER HOLDER (LONG) 彎針台(長)	1
C8-102	BEARING FIXING SCREW 外牙螺母	1
C8-L1	LOOPER SHORT 彎針(短)	1
C8-L2	LOOPER MEDIUM 彎針(中)	1
C8-X3	SCREW 5/16×28 螺釘	1
C8-X31	SCREW 9/64×40 螺釘	1
C8-X32	SCREW 11/64×40 螺釘	3
C8-X32	SCREW 11/04×40 螺釘	3
	SCREW 9/64×40 L10 螺釘	
C8-X50	CODEWN(AV 20 MB/J)	3
C8-X74-1	SCREW1/4×28 螺釘	1
C8-X75	SCREW 11/64×40 螺釘	1
C8-X77	SCREW 11/64×40 螺釘	3
C8-X79	SCREW 3/16×32 螺釘	1
C8-X81	SCREW 9/64×40 螺釘	1
C8-X82	SCREW 9/64×40 螺釘	2
		- "
-		
		100
7		W 10
		70.7
	GIV GIV	
51		
		A
		A
		2




GAUGE PARTS(SP) SP


REF.			
	NO.部件編號	NAME OF PARTS 說明	Amt req需求
	C9-01	NEEDLE CLAMP ASSEMBLY 針夾	1
- 4	C9-02	NEEDLE PLATE 針板	1
		PRESSER FOOT ASSEMBLY 壓腳頭	
	C9-03	PRESSER FOOT ASSEMBLY Rung	
1	C9-05	PRESSER FOOT (F) SPRING 彈簧	1
10	C9-06	PRESSER FOOT ASSEMBLY 壓腳底	1
	C9-07	SUB FEED DOG 導布齒	V 1 (0)
7	C9-09	FEED DOG 送布齒	1
	C9-11	NEEDLE GUARD 針受	1
	C9-14XL	LAPPER ASSEMBLY 導布架喇叭	1
	C9-15	NEEDLE GUARD BRACKET 針受連結	1
		LOOPER (SHORT) 彎針(短)	1
-	C9-A16	LOOPER (SHORT) 管紅(松)	
10	C9-A17	LOOPER (MIDDLE) 彎針(中)	1
1	C9-A18	LOOPER (LONG) 彎針(長)	1
	C9-A19	LOOPER HOLDER (SHORT) 彎針台(短)	1
	C9-A20	LOOPER HOLDER (MIDDLE) 彎針台(中)	_1
1	C9-A21	LOOPER HOLDER (LONG) 彎針台(長)	1
	C9-X9	SCREW 15/64×28 螺釘	
	C0 V44	SCREW 9/64×40 螺釘	1
	C9-X44	SCREW 9/04 × 40 % j	
	C9-X50	SCREW 9/64×40 螺釘	4
	C9-X77	SCREW 11/64×40 螺釘	3
	C9-X79	SCREW 3/16×32 螺釘	1
4	C9-X82	SCREW 9/64×40 螺釘	1
10	C9-X83	STUD SCREW 螺釘銷	2
1	C9-X86	SCREW 3/32×56 合葉螺釘	1
1	C9-X91	SCREW 5/64×60 螺釘	2
-	C0 V03	SCREW 5/64×60	
	C9-X93	NUT O(A) (40 相)	3
	C9-Y05	NUT 9/64×40 螺釘	
	C9-D8-13K	SCREW 9/64×40 螺釘	1
	_		No.
-4			
177			
20			
1			
100			
3.7			
			4 1 1
40	48		
1	44		
6			
			4
			4



GAUGE PARTS (DP) DP


REF. NO.部件編號 C10-01		Amt rocate b
(21U-U1	NAME OF PARTS 說明 NEEDLE CLAMP ASSEMBLY 針夾	Amt req需求
010 01		1
C10-02	NEEDLE PLATE 針板	1_1_
C10-03	SPRING M 彈簧	1
C10-04	SPRING F 彈簧	11
C10-05	SPRING BL 彈簧	1
C10-06	PRESSER FOOT ASSEMBLY 前壓腳底	1 1
C10-07	SUB FEED DOG 導布齒	1
C10-08H	NUT 1/8×44 螺母	1
C10-09	FEED DOG 送布齒	1
C10-09	SPRING BS 彈簧	1
	NEDICOLADO A RE	
C10-11	NEEDLE GUARD 針受	11
C10-14XL	LAPPER ASSEMBLY 導布架喇叭	1
C10-A16	LOOPER (SHORT) 彎針(短)	1
C10-A17	LOOPER (MIDDLE) 彎針(中)	1
C10-A18	LOOPER (LONG) 彎針(長)	_ 1
C10-A19	LOOPER HOLDER (SHORT) 彎針台(短)	1
C10-A20	LOOPER HOLDER (MIDDLE) 彎針台(中)	1
C10-A21	LOOPER HOLDER (LONG) 彎針台(長)	1
C10-X31	SCREW 9/64×40 螺釘	1
010-831	SONEW 4/04 A 40 MBOT	
C10-X32	SCREW 11/64×40 螺釘	1
C10-X44	SCREW 9/64×40 螺釘	3
C10-X50	SCREW 9/64×40 螺釘	3
C10-X65	SCREW 3/32×56 螺釘	1
C10-X77	SCREW 11/64×40 螺釘	3
C10-X79	SCREW 3/16×32 螺釘	1
C10-X73	SCREW 9/64×40 螺釘	1
C10-X82	STUD SCREW 螺釘銷	3
C10-A03	SCREW 3/32×56 螺釘	
C10-X86	OCIC VV 0/02 人 00 「	1
C10-X87	SCREW 1/8×44 L5 螺釘	1
C10-X88	SCREW 1/8×44 螺釘	1
C10-X89	SCREW 3/32×56 螺釘	1
C10-X91	SCREW 5/64×56 螺釘	2
C10-X93	SCREW 1/8×44 螺釘	3
-		100
		70.75
-		
400		
		2
		a
		A
		A
		A
		A
		A
		A
		A
		A





PULLER DEVICE MECHANISM DP \ SP

EF. NO.部件編號		Amt req需
C11-01	NAME OF PARTS 說明 PRESSURE ADJUSTING SCREW 外牙螺母	1
	UPPER WHEEL PRESSER BAR 立軸	1
C11-02		1
C11-03	SPRING 張力彈簧	1
C11-05	WHEEL DIRECTION FIXING DEVICE 拉布輪壓力提柄	1_
C11-06	FRESSER ROD BUSHING 軸套	1
C11-07	UPPER WHEEL SEAT 拉布輪架	1
	UPPER WHEEL CONNECTON 固定軸	1
C11-08	OPPER WHEEL CONNECTON DIA HI	
C11-09	ONE WAY PULL HOLDER 拉柄	1
C11-10	PACKING 防油墊片	1
C11-11	LOWER WHEEL 拉布輪	1
C11-12	ONE WAY TRIANGULAR WHEEL 單向三角軸片	2
	LIDER WILES FLAW	
C11-13	UPPER WHEEL 拉布輪	11
C11-14	ONE WAY STILL BALL 單向滾珠	6
C11-15	ONE WAY STILL SPRING 單向彈簧	6
C11-17	CHOCK RING E型扣環	_ 1
C11-A18-1	FACE PLATE (UPPER) DP上前蓋座	1
	DIDED DITO ABBY	
C11-D1-9	RUBBER PLUG 橡膠塞	4
C11-X09	SCREW 15/64×28 螺釘	1
C11-X19	SCREW 螺釘	2
C11-X31	SCREW 9/64×40 螺釘	1
C11-X47	PRESSER FOOT LIFTER 螺釘	1
C11-X47	SCREW 螺釘	1
C11-X67	SCREW 3/32×56 螺釘	3
C11-X67-1	SCREW 3/32×56 螺釘	6
C11-X67-2	SCREW 3/32×56 螺釘	3
C11-X82	SCREW 9/64×40 螺釘	3
C11-01A	PRESSURE ADJUSTING SCREEW 外牙螺母	2
C11-02A	NUT 螺母	1
C11-03A	PRESSER FOOT LIFTER 手提柄	1
C11-04A	STUD SCREW 固定銷	1
C11-05A	SPRING 張力彈簧	1
	DDECCED RAD CHIDE ACCEMBLY 持大松麻土坦土	
C11-06A	PRESSER BAR GUIDE ASSEMBLY 拉布輪壓力提柄	1
C11-08A	ROLLER PRESSER BAR LIFTER 舌片	1
C11-09A	SCREW PRESSER ROD BUSHING 螺釘	5
C11-10A	PRESSER ROD BUSHING 軸套	1
C11-12A	UPPER WHEEL PRESSER BAR 立軸	4
	OFFER WHILE FRESSER DAY 1/1911	
C11-14A	PULLER SUPPORTER ASSEMBLY 拉布輪架	1
C11-16A	ONE WAY PULL HOLDER 拉柄	1
044 474	LIDDED WHEEL CONNECTON EXCENT	
C11-1/A	I UPPER WHEEL CONNECTON IN A PHI	1
C11-17A C11-18A	UPPER WHEEL CONNECTON 固定軸 FACE PLATE 拉布輪基座	1
C11-18A	FACE PLATE 拉布輪基座	1
C11-18A C11-19A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片	1 1 2
C11-18A C11-19A C11-20A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪	1 2
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪	1 2
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6
C11-18A C11-19A C11-20A C11-21A	FACE PLATE 拉布輪基座 ONE WAY TRIANGULAR WHEEL 單向三角軸片 UPPER WHEEL 拉布輪 ONE WAY STILL BALL 單向滾珠	1 2 1 6



REF. NO.部件編號 C12-01 C12-02	NAME OF PARTS 說明	
C12-02	TANKE OF TAKEO BUST	Amt req需求
012 02	THREAD STAND 六葉線架 CUSHION ASSEMBLY 固定座	1 2
C12-2-1	WASHER 執際	2
C12-03	BASE CUSHION 橡膠墊塊 HEAD COVER 防塵套	2
C12-04 C12-05	OIL TANK 大油壺	1
C12-06	OIL TANK 大油壺 OILER ASSEMBLY 小油瓶	4 1
C12-07 C12-08	NEEDLE 針 TWEEZERS 線夾 SPANNER 固定板手(#7) SPANNER 固定板手(#8)	5
C12-09	SPANNER 固定板手(#7)	1
C12-10	SPANNER 固定板手(#8)	1
C12-11 C12-12	SCREW DRIVER 大起子 SCREW DRIVER 小起子	1 1
C12-13	SCREW DRIVER 小起子 SCREW DRIVER 中起子 THREADLE 腳踏板 SPANNA (4) 28 (#10)	1
C12-14 C12-16	THREADLE 腳踏板	2
C12-16 C12-X1	SPANNER 固定板手(#10) SCREW1/4×28 螺釘	1 2
C12-X1	SCREW 6.2×26 木螺釘	2
		18
		107
7		7 6 7
	CALL	
	· // · // · // · // · // · // · // · /	
		1
		_
		400
-		4 8 6
		3 7
.0.		-
44		
	V31	
	A	
		1
	ALJ'	
P-		47 48
		2
1		- 2
W.		
	100	- 100
4		1
		DA Y
517		
		A